



BOULE
Obere & Untere

0,08 l / 125 mm / 1090, 1091
0,06 l / 110 mm / 1080, 1081



BOULE
Obere & Untere

0,28 l / 165 mm / 1007, 1013
0,20 l / 145 mm / 1006, 1015
0,15 l / 145 mm / 1004, 1015



BOULE Obere
GEX Untere

0,06 l / 135 mm / 1080, 1016
0,08 l / 135 mm / 1090, 1016



BOULE Espresso &
Untere TV GEX

0,08 l / 20x13 mm / 1090, 1017



BOULE Obere
Untere mit
Teekännchen 1

0,28 l / 165 mm / 0,30 l /
1007, 1013, 1099



BOULE Obere
Untere mit
Teekännchen 2

0,28 l / 165 mm / 0,30 l /
1095, 1013, 1096